


INSTALLATION INSTRUCTIONS

LED TV Wall Mount



CAUTION: DO NOT EXCEED MAXIMUM LISTED WEIGHT CAPACITY. SERIOUS INJURY OR PROPERTY DAMAGE MAY OCCUR!

LED-01X



100x100/200x200
400x400/600x600
800x800



ISSUED: OCT. 2012

WARNING

- Do not begin the installation until you have read and understood the instructions and warnings contained in this installation sheet. If you have any questions regarding any of the instruction or warning, please contact your local distributor.
- This mounting bracket was designed to be installed and utilized **ONLY** as specified in this manual. Improper installation of this product may cause damage or serious injury.
- This product should only be installed by someone of good mechanical ability, with basic building experiences and fully understanding of this manual.
- Make sure that the supporting surface will safely support the combined load of the equipment and all attached hardware and components.
- If mounting to wood wall studs, make sure that mounting screws are anchored into the center of the studs. Use of a stud finder is highly recommended.
- Always use an assistant or mechanical lifting equipment to safely lift and position equipment.
- Tighten screws firmly, but do not over tighten. Over tightening can damage the items, greatly reducing their holding power.
- This product intended for indoor use only. Using this product outdoors could lead to product failure and personal injury.

Component Checklist

IMPORTANT: Ensure that you have received all parts according to the component checklist prior to installing. If any parts are missing or faulty, telephone your local distributor for a replacement.



wall plate (x2)
A



adapter bracket (x1)
B



supporting spacer (x1)
C



supporting spacer (x1)
D



clamp(x2)
E



cable tie(x1)
F



wrench (x1)
G

Package M



M5x14 (x4)
M-A



M5x14 (x4)
M-B



M8x20 (x4)
M-C



M6x30 (x4)
M-D



M8x30 (x4)
M-E



D5 washer(x4)
M-F



D8 washer(x4)
M-G



small spacer (x8)
M-H



big spacer (x4)
M-I

Package W



ST6.3x50 (x2)
W-A






concrete anchor (x2)
W-B




D6 washer (x2)
W-C


1a. Mount on Wood Stud Wall



Find and mark the exact location of mounting holes



Drill pilot holes



Screw the wall mount onto the wall

Table 1a.1




The letter "a" stands for the wood stud interval, The letter "L" (see step 2) stands for the actual length of wire rope.

L \ a	406mm(16")	450mm(17.7")	600mm(23.6")
VESA 200x200mm and below			
400x400mm	700mm	710mm	
600x600mm	750mm	750mm	880mm
800x800mm	880mm	880mm	900mm


WARNING

- Make sure that mounting screws are anchored into the center of the studs. Use of a stud finder is highly recommended.
- Installers are responsible to provide hardware for other types of mounting situations.
- Installers must verify that the supporting surface will safely support the combined load of the equipment and all attached hardware and components.

1b. Mount on Solid Brick and Concrete Block



1
Mark the exact location of mounting holes



2
Drill pilot holes




Table 1b.1


The letter "X" stands for the distance between wall plate, The letter "L" (see step 2) stands for the actual length of wire rope.

VESA	200x200mm and below	400x400mm	600x600mm	800x800mm
X	80-100mm	180-220mm	380-420mm	580-620mm
L	400mm	500mm	750mm	900mm



WARNING

- When installing wall mounts on cinder block, verify the actual concrete thickness is at least 1-3/8" (35mm) for using the concrete anchors. Do not drill into mortar joints! Be sure to mount in a solid part of the block, generally 1" (25mm) minimum from the side of the block. It is suggested electric drill on slow setting is used to drill the hole instead of a hammer drill to avoid breaking out the back of the hole when entering a void or cavity.
- Installers must verify that the supporting surface will safely support the combined load of the equipment and all attached hardware and components.


2. Install Adapter Brackets



2-1 For Flat Back Screen



2-2 For Bump-out or Recessed Back Screen




Note: Choose appropriate screws, washers and spacers (if necessary) according to the type of screen.
 • Screw the supporting spacers onto the TV.

⚠ Tighten all screws but do not over tighten.




3. Hang the TV onto the Wall Plate



After the wall mount has been safely secured to the wall, Carefully lift your TV and hook wire rope into the wall plate rail. Make sure your TV is securely and correctly attached.

4. Cable Management



- Fold out tilt supports to access cables.
- Fold tilt supports back once all cables have been installed.

Maintenance

- Check that the bracket is secure and safe to use at regular intervals (at least every three months).
- Please contact your dealer if you have any questions.